

# **789/787B**

ProcessMeter™

## Calibration Manual

September 2002, Rev. 2, 1/17

© 2002-2017 Fluke Corporation. All rights reserved. Specifications are subject to change without notice.  
All product names are trademarks of their respective companies.

## **LIMITED WARRANTY AND LIMITATION OF LIABILITY**

Each Fluke product is warranted to be free from defects in material and workmanship under normal use and service. The warranty period is three years and begins on the date of shipment. Parts, product repairs, and services are warranted for 90 days. This warranty extends only to the original buyer or end-user customer of a Fluke authorized reseller, and does not apply to fuses, disposable batteries, or to any product which, in Fluke's opinion, has been misused, altered, neglected, contaminated, or damaged by accident or abnormal conditions of operation or handling. Fluke warrants that software will operate substantially in accordance with its functional specifications for 90 days and that it has been properly recorded on non-defective media. Fluke does not warrant that software will be error free or operate without interruption.

Fluke authorized resellers shall extend this warranty on new and unused products to end-user customers only but have no authority to extend a greater or different warranty on behalf of Fluke. Warranty support is available only if product is purchased through a Fluke authorized sales outlet or Buyer has paid the applicable international price. Fluke reserves the right to invoice Buyer for importation costs of repair/replacement parts when product purchased in one country is submitted for repair in another country.

Fluke's warranty obligation is limited, at Fluke's option, to refund of the purchase price, free of charge repair, or replacement of a defective product which is returned to a Fluke authorized service center within the warranty period.

To obtain warranty service, contact your nearest Fluke authorized service center to obtain return authorization information, then send the product to that service center, with a description of the difficulty, postage and insurance prepaid (FOB Destination). Fluke assumes no risk for damage in transit. Following warranty repair, the product will be returned to Buyer, transportation prepaid (FOB Destination). If Fluke determines that failure was caused by neglect, misuse, contamination, alteration, accident, or abnormal condition of operation or handling, including overvoltage failures caused by use outside the product's specified rating, or normal wear and tear of mechanical components, Fluke will provide an estimate of repair costs and obtain authorization before commencing the work. Following repair, the product will be returned to the Buyer transportation prepaid and the Buyer will be billed for the repair and return transportation charges (FOB Shipping Point).

THIS WARRANTY IS BUYER'S SOLE AND EXCLUSIVE REMEDY AND IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. FLUKE SHALL NOT BE LIABLE FOR ANY SPECIAL, INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES OR LOSSES, INCLUDING LOSS OF DATA, ARISING FROM ANY CAUSE OR THEORY.

Since some countries or states do not allow limitation of the term of an implied warranty, or exclusion or limitation of incidental or consequential damages, the limitations and exclusions of this warranty may not apply to every buyer. If any provision of this Warranty is held invalid or unenforceable by a court or other decision-maker of competent jurisdiction, such holding will not affect the validity or enforceability of any other provision.

11/99

# Table of Contents

| Title                                                 | Page |
|-------------------------------------------------------|------|
| Introduction .....                                    | 1    |
| How to Contact Fluke .....                            | 1    |
| Safety Information .....                              | 2    |
| Specifications .....                                  | 5    |
| Required Equipment .....                              | 9    |
| Basic Maintenance .....                               | 10   |
| How to Clean .....                                    | 10   |
| Battery Replacement .....                             | 10   |
| Battery Life .....                                    | 11   |
| Check and Replace Fuses .....                         | 12   |
| Performance Verification .....                        | 12   |
| Preparation .....                                     | 13   |
| Loop Power Test (789 only) .....                      | 14   |
| Current Sourcing Test .....                           | 15   |
| Current Measurement Test .....                        | 16   |
| Diode Function Test .....                             | 17   |
| Continuity Function Test .....                        | 19   |
| Resistance Measurement Test .....                     | 20   |
| DC Millivolts Measurement Test .....                  | 22   |
| DC Volts Measurement Tests .....                      | 23   |
| AC Volts Measurement Test .....                       | 24   |
| Frequency Measurement Test .....                      | 25   |
| Calibration Adjustment .....                          | 26   |
| Preparation .....                                     | 26   |
| Procedure for Models with Firmware Version <2.0 ..... | 27   |
| AC Voltage Adjustment .....                           | 27   |
| Frequency Adjustment .....                            | 28   |
| DC Voltage Adjustment .....                           | 29   |
| DC Millivolts Adjustment .....                        | 29   |
| Ohms Adjustment .....                                 | 30   |
| Diode Adjustment .....                                | 30   |
| Milliamps DC Adjustment .....                         | 31   |
| Amps DC Adjustment .....                              | 31   |
| Amps AC Adjustment .....                              | 32   |
| Milliamps Output Adjustment .....                     | 32   |
| Procedure for Models with Firmware Version ≥2.0 ..... | 33   |
| Calibration Adjustment Counter .....                  | 33   |
| Calibration Adjustment Password .....                 | 33   |
| How to Change the Password .....                      | 33   |

How to Restore the Default Password ..... 35

Meter Keys Used in the Calibration Steps ..... 36

Calibration Adjustment ..... 36

Replacement Parts and Accessories ..... 38

## Introduction

### Warning

The information provided in this manual is for the use of qualified personnel only. Do not perform the calibration verification tests or calibration procedures described in this manual unless you are qualified to do so.

### Caution

The ProcessMeter™ contains parts that can be damaged by static discharge. Follow the standard practices for handling static sensitive devices.

The *Calibration Manual* for the 789/787B ProcessMeter (Meter, Product, or UUT) provides the following information:

- Precautions and Safety information
- Specifications
- Basic maintenance (cleaning, replacing the batteries and fuses)
- Calibration verification test procedures
- Calibration adjustment procedures
- Accessories and replaceable parts

All illustrations in this manual show the 789. For complete operating instructions, refer to the *789/787B ProcessMeter Users Manual* (provided on CD-ROM with the Product).

## Safety Information

A **Warning** identifies conditions and procedures that are dangerous to the user. A **Caution** identifies conditions and procedures that can cause damage to the Product or the equipment under test.

International symbols used on the Meter and in this manual are explained in Table 1.

### Warning

To prevent possible electrical shock, fire, or personal injury:

- Read all safety information before you use the Product.
- Carefully read all instructions.
- Do not alter the Product and use only as specified, or the protection supplied by the Product can be compromised.
- Remove the batteries if the Product is not used for an extended period of time, or if stored in temperatures above 50 °C. If the batteries are not removed, battery leakage can damage the Product.
- The battery door must be closed and locked before you operate the Product.
- Replace the batteries when the low battery indicator shows to prevent incorrect measurements.
- Comply with local and national safety codes. Use personal protective equipment (approved rubber gloves, face protection, and flame-resistant clothes) to prevent shock and arc blast injury where hazardous live conductors are exposed.
- Do not apply more than the rated voltage, between the terminals or between each terminal and earth ground.
- Do not work alone.
- Limit operation to the specified measurement category, voltage, or amperage ratings.
- Use Product-approved measurement category (CAT), voltage, and amperage rated accessories (probes, test leads, and adapters) for all measurements.
- Measure a known voltage first to make sure that the Product operates correctly.
- Use the correct terminals, function, and range for measurements.
- Do not touch voltages >30 V ac rms, 42 V ac peak, or 60 V dc.
- Do not use the Product around explosive gas, vapor, or in damp or wet environments.
- Do not use the Product if it operates incorrectly.
- Examine the case before you use the Product. Look for cracks or missing plastic. Carefully look at the insulation around the terminals.
- Do not use test leads if they are damaged. Examine the test leads for damaged insulation, exposed metal, or if the wear indicator shows. Check test lead continuity.
- Keep fingers behind the finger guards on the probes.
- Only use probes, test leads, and accessories that have the same measurement category, voltage, and amperage ratings as the Product.

- Remove all probes, test leads, and accessories before the battery door is opened.
- Remove all probes, test leads, and accessories that are not necessary for the measurement.
- Do not exceed the Measurement Category (CAT) rating of the lowest rated individual component of a Product, probe, or accessory.
- Do not use test leads if they are damaged. Examine the test leads for damaged insulation and measure a known voltage.
- Do not use a current measurement as an indication that a circuit is safe to touch. A voltage measurement is necessary to know if a circuit is hazardous.
- Do not use the Product if it is altered or damaged.
- Do not use in CAT III or CAT IV environments without the protective cap installed on test probes. The protective cap decreases the exposed probe metal to <4 mm. This decreases the possibility of arc flash from short circuits.

 **Caution**

To prevent damage to the Product or the test equipment:

- Disconnect the power and discharge all high voltage capacitors before testing resistance, diodes, or continuity.
- Use the proper terminals, switch setting, and range for the measurement or sourcing applications.

**Table 1. International Symbols**

| Symbol                                                                             | Description                                                                                                                                                                                                                                                                                                                                                                                                                          | Symbol                                                                            | Description                                               |
|------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|-----------------------------------------------------------|
|   | WARNING. RISK OF DANGER.                                                                                                                                                                                                                                                                                                                                                                                                             |  | WARNING. HAZARDOUS VOLTAGE. Risk of electric shock.       |
|   | Consult user documentation.                                                                                                                                                                                                                                                                                                                                                                                                          |  | Conforms to relevant South Korean EMC Standards           |
|   | Conforms to European Union directives                                                                                                                                                                                                                                                                                                                                                                                                |  | Minimum fuse interrupt rating.                            |
|   | Certified by CSA Group to North American safety standards.                                                                                                                                                                                                                                                                                                                                                                           |  | Conforms to relevant Australian Safety and EMC standards. |
|   | AC (Alternating Current)                                                                                                                                                                                                                                                                                                                                                                                                             |  | Earth                                                     |
|   | DC (Direct Current)                                                                                                                                                                                                                                                                                                                                                                                                                  |  | Fuse                                                      |
|   | Battery                                                                                                                                                                                                                                                                                                                                                                                                                              |  | Double Insulated                                          |
| <b>CAT II</b>                                                                      | Measurement Category II is applicable to test and measuring circuits connected directly to utilization points (socket outlets and similar points) of the low-voltage MAINS installation.                                                                                                                                                                                                                                             |                                                                                   |                                                           |
| <b>CAT III</b>                                                                     | Measurement Category III is applicable to test and measuring circuits connected to the distribution part of the building's low-voltage MAINS installation.                                                                                                                                                                                                                                                                           |                                                                                   |                                                           |
| <b>CAT IV</b>                                                                      | Measurement Category IV is applicable to test and measuring circuits connected at the source of the building's low-voltage MAINS installation.                                                                                                                                                                                                                                                                                       |                                                                                   |                                                           |
|  | This product complies with the WEEE Directive marking requirements. The affixed label indicates that you must not discard this electrical/electronic product in domestic household waste. Product Category: With reference to the equipment types in the WEEE Directive Annex I, this product is classed as category 9 "Monitoring and Control Instrumentation" product. Do not dispose of this product as unsorted municipal waste. |                                                                                   |                                                           |

## Specifications

- All specifications apply from +18 °C to +28 °C unless stated otherwise.
- All specifications assume a 5-minute warm-up period.
- The standard specification interval is 1 year.

### Note

“Counts” refers to the number of increments or decrements of the least significant digit.

### DC Volts Measurement

| Range (V dc)                                                                                                                                                                                                | Resolution | Accuracy, $\pm$ (% of Reading + Counts) |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------|-----------------------------------------|
| 4.000                                                                                                                                                                                                       | 0.001 V    | 0.1 % + 1                               |
| 40.00                                                                                                                                                                                                       | 0.01 V     | 0.1 % + 1                               |
| 400.0                                                                                                                                                                                                       | 0.1 V      | 0.1 % + 1                               |
| 1000                                                                                                                                                                                                        | 1 V        | 0.1 % + 1                               |
| Input impedance: 10 M $\Omega$ (nominal), <100 pF<br>Normal mode rejection ratio: >60 dB at 50 Hz or 60 Hz<br>Common mode rejection ratio: >120 dB at dc, 50 Hz, or 60 Hz<br>Overvoltage protection: 1000 V |            |                                         |

### DC Millivolts Measurement

| Range (mV dc) | Resolution | Accuracy, $\pm$ (% of Reading + Counts) |
|---------------|------------|-----------------------------------------|
| 400.0         | 0.1 mV     | 0.1 % + 2                               |

### AC Volts Measurement

| Range (ac)                                                                                                                                                                                                                                                                                                                                             | Resolution | Accuracy, $\pm$ (% of Reading + Counts) |                 |                  |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------|-----------------------------------------|-----------------|------------------|
|                                                                                                                                                                                                                                                                                                                                                        |            | 50 Hz to 60 Hz                          | 45 Hz to 200 Hz | 200 Hz to 500 Hz |
| 400.0 mV                                                                                                                                                                                                                                                                                                                                               | 0.1 mV     | 0.7 % + 4                               | 1.2 % + 4       | 7.0 % + 4        |
| 4.000 V                                                                                                                                                                                                                                                                                                                                                | 0.001 V    | 0.7 % + 2                               | 1.2 % + 4       | 7.0 % + 4        |
| 40.00 V                                                                                                                                                                                                                                                                                                                                                | 0.01 V     | 0.7 % + 2                               | 1.2 % + 4       | 7.0 % + 4        |
| 400.0 V                                                                                                                                                                                                                                                                                                                                                | 0.1 V      | 0.7 % + 2                               | 1.2 % + 4       | 7.0 % + 4        |
| 1000 V                                                                                                                                                                                                                                                                                                                                                 | 1 V        | 0.7 % + 2                               | 1.2 % + 4       | 7.0 % + 4        |
| Specifications are valid from 5 % to 100 % of amplitude range.<br>AC conversion: true rms<br>Maximum crest factor: 3 (between 50 and 60 Hz)<br>For non-sinusoidal waveforms, add $\pm$ (2 % reading + 2 % f.s.) typical<br>Input impedance: 10 M $\Omega$ (nominal), <100 pF, ac-coupled<br>Common mode rejection ratio: >60 dB at dc, 50 Hz, or 60 Hz |            |                                         |                 |                  |

### AC Current Measurement

| Range<br>45 Hz to 2 kHz                                                                                                                                                                                                                                                                                                                                                   | Resolution | Accuracy,<br>±(% of Reading + Counts) | Typical Burden<br>Voltage |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------|---------------------------------------|---------------------------|
| 1.000 A (Note)                                                                                                                                                                                                                                                                                                                                                            | 0.001 A    | 1 % + 2                               | 1.5 V/A                   |
| <i>Note: 440 mA continuous, 1 A 30 seconds maximum</i><br><br><i>Specifications are valid from 5 % to 100 % of amplitude range.</i><br><i>AC conversion: true rms</i><br><i>Maximum crest factor: 3 (between 50 and 60 Hz)</i><br><i>For non-sinusoidal waveforms, add ±( 2 % reading + 2 % f.s.) typical</i><br><i>Overload protection 440 mA, 1000 V fast-blow fuse</i> |            |                                       |                           |

### DC Current Measurement

| Range                                                                                                                   | Resolution | Accuracy<br>±(% of Reading + Counts) | Typical Burden<br>Voltage |
|-------------------------------------------------------------------------------------------------------------------------|------------|--------------------------------------|---------------------------|
| 30.000 mA                                                                                                               | 0.001 mA   | 0.05 % + 2                           | 14 mV/mA                  |
| 1.000 A (Note)                                                                                                          | 0.001 A    | 0.2 % + 2                            | 1.5 V/A                   |
| <i>Note: 440 mA continuous, 1 A 30 seconds maximum</i><br><br><i>Overload protection: 440 mA, 1000 V fast-blow fuse</i> |            |                                      |                           |

### Ohms Measurement

| Range                                                                        | Resolution | Measurement Current | Accuracy<br>±(% of Reading + Counts) |
|------------------------------------------------------------------------------|------------|---------------------|--------------------------------------|
| 400.0 Ω                                                                      | 0.1 Ω      | 310 μA              | 0.2 % + 2                            |
| 4.000 kΩ                                                                     | 0.001 kΩ   | 31 μA               | 0.2 % + 1                            |
| 40.00 kΩ                                                                     | 0.01 kΩ    | 2.5 μA              | 0.2 % + 1                            |
| 400.0 kΩ                                                                     | 0.1 kΩ     | 250 nA              | 0.2 % + 1                            |
| 4.000 MΩ                                                                     | 0.001 MΩ   | 250 nA              | 0.35 % + 3                           |
| 40.00 MΩ                                                                     | 0.01 MΩ    | 125 nA              | 2.5 % + 3                            |
| <i>Overload protection: 1000 V</i><br><i>Open circuit voltage: &lt;3.9 V</i> |            |                     |                                      |

### Frequency Counter Accuracy

| Range                                              | Resolution | Accuracy<br>±(% of Reading + Counts) |
|----------------------------------------------------|------------|--------------------------------------|
| 199.99 Hz                                          | 0.01 Hz    | 0.005 % + 1                          |
| 1999.9 Hz                                          | 0.1 Hz     | 0.005 % + 1                          |
| 19.999 kHz                                         | 0.001 kHz  | 0.005 % + 1                          |
| <i>Display updates 3 times/second at &gt;10 Hz</i> |            |                                      |

### Frequency Counter Sensitivity

| Input Range                                                                   | Minimum Sensitivity (rms Sinewave)<br>5 Hz to 5 kHz* |                                                     |
|-------------------------------------------------------------------------------|------------------------------------------------------|-----------------------------------------------------|
|                                                                               | AC                                                   | DC<br>(approximate trigger level 5 % of full scale) |
| 400 mV                                                                        | 150 mV (50 Hz to 5 kHz)                              | 150 mV                                              |
| 4 V                                                                           | 1 V                                                  | 1 V                                                 |
| 40 V                                                                          | 4 V                                                  | 4 V                                                 |
| 400 V                                                                         | 40 V                                                 | 40 V                                                |
| 1000 V                                                                        | 400 V                                                | 400 V                                               |
| *Usable 0.5 Hz to 20 kHz with reduced sensitivity.<br>10 <sup>6</sup> VHz max |                                                      |                                                     |

### Diode Test and Continuity Test

Diode test indication ..... Displays voltage drop across device, 2.0 V full scale. Nominal test current 0.3 mA at 0.6 V. Accuracy  $\pm(2\% + 1 \text{ count})$ .

Continuity test indication ..... Continuous audible tone for test resistance  $<100\ \Omega$

Open circuit voltage ..... 2.9 V

Short circuit current ..... 310  $\mu\text{A}$  typical

Overload protection ..... 1000 V rms

**Loop Power Supply Voltage** ..... 24 V, Short Circuit protected

### DC Current Output

Source mode:

Span ..... 0 mA or 4 mA to 20 mA, with overrange to 24 mA

Accuracy ..... 0.05 % of span

Compliance voltage ..... 28 V with battery voltage  $>\sim 4.5\ \text{V}$

Simulate Mode

Span ..... 0 mA or 4 mA to 20 mA, with overrange to 24 mA

Accuracy ..... 0.05 % of span

Loop voltage ..... 24 V nominal, 48 V maximum, 15 V minimum

Compliance voltage ..... 21 V for 24 V supply

Burden voltage .....  $<3\ \text{V}$

## General Specifications

|                                                              |                                                                                                                                                                                                                                                                                                                                                                |
|--------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Maximum Voltage between any Terminal and Earth Ground</b> | 1000 V                                                                                                                                                                                                                                                                                                                                                         |
| <b>Fuse Protection for mA inputs</b>                         | 0.44 A, 1000 V IR 10 kA                                                                                                                                                                                                                                                                                                                                        |
| <b>Power</b>                                                 |                                                                                                                                                                                                                                                                                                                                                                |
| Battery Type                                                 | IEC LR6 (AA Alkaline)                                                                                                                                                                                                                                                                                                                                          |
| Quantity                                                     | 4                                                                                                                                                                                                                                                                                                                                                              |
| <b>Temperature</b>                                           |                                                                                                                                                                                                                                                                                                                                                                |
| Operating                                                    | -20 °C to +55 °C                                                                                                                                                                                                                                                                                                                                               |
| Storage                                                      | -40 °C to +60 °C                                                                                                                                                                                                                                                                                                                                               |
| <b>Altitude</b>                                              |                                                                                                                                                                                                                                                                                                                                                                |
| Operating                                                    | ≤2000 m                                                                                                                                                                                                                                                                                                                                                        |
| Storage                                                      | ≤12 000 m                                                                                                                                                                                                                                                                                                                                                      |
| <b>Frequency Overload Protection</b>                         | 10 <sup>6</sup> V Hz max                                                                                                                                                                                                                                                                                                                                       |
| <b>Temperature coefficient</b>                               |                                                                                                                                                                                                                                                                                                                                                                |
| Measurements                                                 | 0.05 x specified accuracy per °C for temperatures <18 °C or >28 °C                                                                                                                                                                                                                                                                                             |
| Source                                                       | 0.1 x specified accuracy per °C for temperatures <18 °C or >28 °C                                                                                                                                                                                                                                                                                              |
| <b>Relative humidity</b>                                     | 95 % up to 30 °C, 75 % up to 40 °C, 45 % up to 50 °C, and 35 % up to 55 °C                                                                                                                                                                                                                                                                                     |
| <b>Vibration</b>                                             | Random 2g, 5 to 500 Hz                                                                                                                                                                                                                                                                                                                                         |
| <b>Shock</b>                                                 | 1 meter drop test                                                                                                                                                                                                                                                                                                                                              |
| <b>Size</b>                                                  | 10.0 cm X 20.3 cm X 5.0 cm (3.94 in X 8.00 in X 1.97 in)                                                                                                                                                                                                                                                                                                       |
| <b>Weight</b>                                                | 610 g (1.6 lb)                                                                                                                                                                                                                                                                                                                                                 |
| <b>Safety</b>                                                |                                                                                                                                                                                                                                                                                                                                                                |
| General                                                      | IEC 61010-1: Pollution Degree 2                                                                                                                                                                                                                                                                                                                                |
| Measurement                                                  | IEC 61010-2-033: CAT IV 600 V / CAT III 1000 V                                                                                                                                                                                                                                                                                                                 |
| <b>Electromagnetic Compatibility (EMC)</b>                   | Accuracy for all ProcessMeter functions is not specified in RF field >3 V/m                                                                                                                                                                                                                                                                                    |
| International                                                | IEC 61326-1: Portable Electromagnetic Environment; IEC 61326-2-2<br>CISPR 11: Group 1, Class A                                                                                                                                                                                                                                                                 |
|                                                              | <i>Group 1: Equipment has intentionally generated and/or uses conductively-coupled radio frequency energy that is necessary for the internal function of the equipment itself.</i>                                                                                                                                                                             |
|                                                              | <i>Class A: Equipment is suitable for use in all establishments other than domestic and those directly connected to a low-voltage power supply network that supplies buildings used for domestic purposes. There may be potential difficulties in ensuring electromagnetic compatibility in other environments due to conducted and radiated disturbances.</i> |
|                                                              | <i>Caution: This equipment is not intended for use in residential environments and may not provide adequate protection to radio reception in such environments.</i>                                                                                                                                                                                            |
|                                                              | <i>Emissions that exceed the levels required by CISPR 11 can occur when the equipment is connected to a test object.</i>                                                                                                                                                                                                                                       |
| Korea (KCC)                                                  | Class A Equipment (Industrial Broadcasting & Communication Equipment)                                                                                                                                                                                                                                                                                          |
|                                                              | <i>Class A: Equipment meets requirements for industrial electromagnetic wave equipment and the seller or user should take notice of it. This equipment is intended for use in business environments and not to be used in homes.</i>                                                                                                                           |
| USA (FCC)                                                    | 47 CFR 15 subpart B. This product is considered an exempt device per clause 15.103.                                                                                                                                                                                                                                                                            |

## Required Equipment

Equipment and software required to perform the procedures in this manual are identified in Table 2.

If the recommended equipment model is not available, in some cases other equipment can be substituted as long as it meets the specifications indicated.

### ⚠⚠ Warning

**To avoid safety hazards and equipment damage during the calibration procedure, use the specified calibration equipment listed in Table 2. Using unspecified equipment can jeopardize the calibration verification test and pose safety hazards.**

### Note

*Unless otherwise indicated, all connection diagrams for the calibration verification tests in this manual showing a calibrator or digital multimeter use a Fluke 5522A calibrator, Fluke 8508A Reference Multimeter, Keysight 3458A DMM, or equivalent.*

*If you are using a different calibrator or DMM, make the connections appropriate for that instrument.*

**Table 2. Required Equipment and Software**

| Equipment                             | Minimum Specifications                                                                    | Recommended Model                       |
|---------------------------------------|-------------------------------------------------------------------------------------------|-----------------------------------------|
| Calibration Source                    | No Substitute                                                                             | Fluke Model 5522A or equivalent         |
| Digital Multimeter                    | No Substitute                                                                             | Fluke 8508A, Keysight 3458A             |
| Test Leads, low leakage, RG-58/U type | Leakage resistance > than $1.0 \times 10^{13} \Omega$ at 45 °C and 75 % relative humidity | Fluke 5440A-7002 Low Thermal Test Leads |
| 1-k $\Omega$ shunt                    | 1 k $\Omega$ , 1 %, 2 watts, Low TC is preferable                                         | ---                                     |

## Basic Maintenance

### How to Clean

#### Warning

**To prevent electrical shock or damage, never allow water inside the case of the ProcessMeter.**

If the ProcessMeter requires cleaning, wipe it down with a cloth that is lightly dampened with water or a mild detergent.

#### Caution

**Do not use aromatic hydrocarbons, chlorinated solvents, or methanol-based fluids when wiping down the ProcessMeter. To avoid damaging the case, never apply solvents to the case of the ProcessMeter.**


### Battery Replacement

#### Warning

**For safe operation and maintenance, repair the Product before use if the battery leaks.**

To replace the batteries, see Figure 1:

1. Remove the test leads and turn the Meter OFF.
2. With a standard blade hand screwdriver, turn each battery door screw counterclockwise so that the slot is parallel with the screw picture molded into the case.
3. Lift off the battery door.
4. Remove the batteries.
5. Replace with four new AA alkaline batteries.
6. Reinstall the battery door and tighten screws.



**Figure 1. Replacing the Batteries and Fuses**

anw037.eps

## Battery Life

### ⚠⚠ Warning

**To prevent possible electrical shock, fire, or personal injury, replace the batteries when the low battery indicator shows.**

The ProcessMeter is powered by four AA alkaline batteries.

Table 3 shows typical alkaline battery life. To preserve battery life:

- Use current simulation instead of sourcing when possible.
- Avoid using the backlight.
- Do not disable the automatic power-off feature.
- Turn the ProcessMeter off when not in use.

**Table 3. Typical Alkaline Battery Life**

| ProcessMeter Operation           | Hours |
|----------------------------------|-------|
| Measuring any parameter          | 140   |
| Simulating Current               | 140   |
| Sourcing 12 mA into 500 $\Omega$ | 10    |

## Check and Replace Fuses

### Warning

**To prevent possible electrical shock, fire, or personal injury, use only the specified replacement fuses.**

Both current input jacks are fused with separate 440 mA fuses. To determine if a fuse is blown:

1. Turn the rotary function switch to  $\frac{\approx}{mA}$ .
2. Plug the black test lead into COM, and the red test lead into the  $A\approx$  input.
3. Using an ohmmeter, check the resistance between the ProcessMeter test leads. If the resistance is about 1  $\Omega$ , the fuse is good. An open reading means that fuse F2 is blown.
4. Move red test lead to  $mA\approx$ .
5. Using an ohmmeter, check the resistance between the ProcessMeter test leads. If the resistance is about 14  $\Omega$ , the fuse is good. An open means that fuse F1 is blown.

If a fuse is blown, replace it as follows. Refer to Figure 1 as necessary:

1. Remove the test leads from the ProcessMeter and turn the ProcessMeter OFF.
2. With a standard blade hand screwdriver, turn each battery compartment door screw counterclockwise so that the slot is parallel with the screw picture molded into the case.
3. Remove either fuse by gently prying one end loose, then sliding the fuse out of its bracket.
4. Replace the blown fuse(s).
5. Replace the battery compartment door. Secure the door by turning the screws one-quarter turn clockwise.

## Performance Verification

### Warning

**To prevent electrical shock:**

- **Only qualified personnel should perform calibration verification tests that use high voltages.**
- **Always place the calibrator in the Standby (STBY) mode between tests and before handling the test connections or test cables.**

Calibration verification tests confirm the complete functionality of the ProcessMeter and check the accuracy of each ProcessMeter function against its specifications. If the ProcessMeter fails any calibration verification test, it needs calibration adjustment or repair.

The ProcessMeter's performance and accuracy are specified for one year after calibration at operating temperatures of +18 °C to +28 °C (64 °F to 82 °F), in relative humidity to 90 %. The specifications assume the ProcessMeter has been warmed up for 5 minutes before use.

To perform the calibration verification tests, it is not necessary to open the case; no adjustments are necessary. Merely make the required connections, source the

designated values, and determine if the reading on the ProcessMeter or the multimeter falls within the acceptable range indicated.

These calibration verification test procedures assume that the person performing the tests has read the *789/787B Users Manual*, knows how to select functions and ranges on the ProcessMeter, and knows how to operate the required equipment.

*Note*

*Calibration verification tests for the ProcessMeter can be performed manually, or they can be computer-automated (using Fluke's MET/CAL® Calibration Software). This document provides the procedures necessary to perform the calibration verification test manually.*

## **Preparation**

*Note*

*Throughout the calibration verification tests, "UUT" (unit under test) refers to the ProcessMeter; the word "multimeter" is reserved for the digital multimeter identified in the required equipment listed in Table 2.*

*Unless otherwise indicated, all connection diagrams for the calibration verification tests in this manual showing a calibrator or digital multimeter use a Fluke 5522A calibrator or 8508A.*

*If using a different calibrator or DMM make the connections appropriate for your instrument.*

To prepare the UUT for the calibration verification tests:

1. Make sure that the required equipment is available (see Table 2).
2. Make sure that the fuses in the UUT are intact. See "Checking and Replacing a Fuse" earlier in this manual.
3. Make sure the UUT has fresh batteries. See "Replacing the Batteries" earlier in this manual.
4. Warm up the calibrator and multimeter as required by their specifications.
5. Remove all input cables from the front of the UUT.
6. Make sure that the UUT is in a stable ambient temperature between 18 °C and 28 °C (64.4 °F and 82.4 °F) and that it has been warmed up for 5 minutes.

### Loop Power Test (789 only)

1. Enable the dc volts autorange function of the multimeter.
2. Turn the rotary knob of the UUT to **LOOP POWER**.
3. Measure the open circuit voltage of the UUT and verify it is >29.2 V and <32 V.
4. Press  $\bigcirc$  (BLUE) on the UUT to enable the 250  $\Omega$  HART resistor.
5. Repeat step 3.
6. Disable the 250  $\Omega$  HART resistor by pressing  $\bigcirc$  (BLUE).
7. Connect the 1-k $\Omega$  shunt across **SOURCE +** and **SOURCE -** of the UUT.
8. Measure the loaded down voltage and verify it is >23.8 V and <32 V, see Figure 2.
9. Remove the 1-k $\Omega$  shunt.
10. Disconnect the UUT from the multimeter and turn the UUT off.
11. Select the dc current function on the multimeter and set it to the 1-amp range (a 0.1  $\Omega$  shunt is used in the 1-amp range).
12. Connect the current input terminals of the multimeter to the **SOURCE +** and **SOURCE -** terminals of the UUT.
13. Turn the rotary knob of the UUT to **LOOP POWER**.
14. Verify the short circuit current is >24 mA and <35 mA.




Figure 2. Verifying Loop Power

adm006F.EPS

## Current Sourcing Test

1. Put the calibrator in **Standby** (STBY) mode.
2. Connect the **SOURCE + (A $\overline{\sim}$ )** and **– (mA $\overline{\sim}$ )** terminals on the UUT to the current terminals on the multimeter as shown in Figure 3.
3. Put the multimeter in the dc mA mode and manually select the 100 mA range. (Do not allow the multimeter to autorange.)
4. Turn the UUT rotary switch in the **OUTPUT mA $\overline{\sim}$**  position.
5. Use the **SpanCheck**, **%STEP** and **COARSE** keys on the UUT to apply the values shown in Table 4 and compare the readings on the multimeter to the acceptable readings shown.

Table 4. Current Sourcing Test

| 789 Range          | 789 Output Current | Minimum Acceptable Multimeter Reading | Maximum Acceptable Multimeter Reading |
|--------------------|--------------------|---------------------------------------|---------------------------------------|
| No Range Switching | 4.000 mA           | 3.990 mA                              | 4.010 mA                              |
| No Range Switching | 12.000 mA          | 11.990 mA                             | 12.010 mA                             |
| No Range Switching | 20.000 mA          | 19.990 mA                             | 20.010 mA                             |




Figure 3. Current Sourcing Connections Using the HP 3458A

adm001F.EPS

## Current Measurement Test

1. Put the calibrator in **Standby** (STBY) mode.
2. Put the UUT rotary switch in the  $\overset{\sim}{mA}$  position.
3. Connect the calibrator to the **COM** and  $\overset{\sim}{mA}$  terminals on the UUT as shown in Figure 4.
4. Apply the values from the calibrator shown in Table 5 and compare the readings on the UUT to the acceptable readings shown.
5. Connect the calibrator to the **COM** and **A** terminals on the UUT.
6. Apply the values from the calibrator shown in Table 6 and compare the readings on the UUT to the acceptable readings shown.
7. Press  $\bigcirc$  (BLUE) on the UUT to toggle to ac amps.
8. Apply the values from the calibrator shown in Table 7 and compare the readings on the UUT to the acceptable readings shown.




Figure 4. Current Measurement Test Connections

adm003F.EPS

**Table 5. DC mA Test**

| 789 Range          | Calibrator DC Current | Minimum Acceptable Reading | Maximum Acceptable Reading |
|--------------------|-----------------------|----------------------------|----------------------------|
| No Range Switching | 4.000 mA              | 3.996 mA                   | 4.004 mA                   |
| No Range Switching | 12.000 mA             | 11.992 mA                  | 12.008 mA                  |
| No Range Switching | 20.000 mA             | 19.988 mA                  | 20.012 mA                  |

**Table 6. DC Amp Test**

| 789 Range          | Calibrator DC Current | Minimum Acceptable Reading | Maximum Acceptable Reading |
|--------------------|-----------------------|----------------------------|----------------------------|
| No Range Switching | 0.100 A               | 0.098 A                    | 0.102 A                    |
| No Range Switching | 0.400 A               | 0.397 A                    | 0.403 A                    |

**Table 7. AC Amp Test**

| 789 Range          | Calibrator AC Current and Frequency | Minimum Acceptable Reading | Maximum Acceptable Reading |
|--------------------|-------------------------------------|----------------------------|----------------------------|
| No Range Switching | 0.100 A @ 60 Hz                     | 0.097 A                    | 0.103 A                    |
| No Range Switching | 0.400 A @ 60 Hz                     | 0.394 A                    | 0.406 A                    |

### **Diode Function Test**

1. Put the calibrator in **Standby** (STBY) mode.
2. Turn the UUT rotary switch in the  $\Omega \rightarrow +$  position.
3. Press  $\bigcirc$  (BLUE) to select diode test ( $\rightarrow +$ ).
4. Connect the calibrator to the **COM** and  $\Omega \rightarrow +$  terminals on the UUT as shown in Figure 5.
5. Apply 2.0 V dc from the calibrator.
6. The UUT should read between 1.959 V and 2.041 V.
7. Put the calibrator in **Standby** (STBY) mode; then disconnect the calibrator from the UUT.
8. Put the multimeter in the dc mA (autorange) function.
9. Connect the current terminals of the multimeter to the **COM** and  $\Omega \rightarrow +$  terminals on the UUT.

The multimeter should read close to 0.3 mA. (There is no tolerance specification for this current. This test just makes sure that the diode test current source is operating.)




Figure 5. Diode Test Connections

adm007F.EPS

## Continuity Function Test

1. Put the calibrator in **Standby** (STBY) mode, and turn the UUT rotary switch to the  $\Omega$  position.
2. Connect the calibrator to the **COM** and  $\Omega$  terminals on the UUT as shown in Figure 6.
3. Press  (continuity beeper) on the UUT to select the continuity test.
4. Using the calibrator, apply a resistance output of  $260 \pm 20 \Omega$ . The beeper should stay off.
5. Using the calibrator, apply a resistance output of  $100 \pm 10 \Omega$ . The beeper should turn on.




Figure 6. Continuity Test Connections

adm008F.EPS

### Resistance Measurement Test

1. Put the calibrator in **Standby** (STBY) mode.
2. Put the UUT rotary switch in the  $\Omega$  position.
3. Connect the **OUTPUT** and **SENSE** leads of the calibrator to the UUT as shown by the solid and dotted lines in Figure 7.
4. Apply the calibrator resistance values in Table 8 in the UUT 400  $\Omega$  to 40 k $\Omega$  range. Compare the readings on the UUT to the acceptable readings shown.
5. Change the connections to the UUT. Using the Fluke 5440A-7002 low thermal leads, connect the calibrator to the UUT as shown by the solid lines in Figure 7.
6. Apply the rest of the calibrator resistance values in Table 8 (400 k $\Omega$  range and above). Compare the readings on the UUT to the acceptable readings shown.




Figure 7. Resistance Measurement Test Connections

adm004F.EPS

**Table 8. Resistance Measurement Test**

| Range          | Calibrator Resistance | Calibrator Compensation Mode | Minimum Reading  | Maximum Reading  |
|----------------|-----------------------|------------------------------|------------------|------------------|
| 400 $\Omega$   | 120 $\Omega$          | 2-Wire                       | 119.6 $\Omega$   | 120.4 $\Omega$   |
| 400 $\Omega$   | 300 $\Omega$          | 2-Wire                       | 299.2 $\Omega$   | 300.8 $\Omega$   |
| 4 k $\Omega$   | 1.2 k $\Omega$        | 2-Wire                       | 1.197 k $\Omega$ | 1.203 k $\Omega$ |
| 4 k $\Omega$   | 3 k $\Omega$          | 2-Wire                       | 2.993 k $\Omega$ | 3.007 k $\Omega$ |
| 40 k $\Omega$  | 12 k $\Omega$         | 2-Wire                       | 11.97 k $\Omega$ | 12.03 k $\Omega$ |
| 40 k $\Omega$  | 30 k $\Omega$         | 2-Wire                       | 29.93 k $\Omega$ | 30.07 k $\Omega$ |
| 400 k $\Omega$ | 120 k $\Omega$        | OFF                          | 119.7 k $\Omega$ | 120.3 k $\Omega$ |
| 400 k $\Omega$ | 200 k $\Omega$        | OFF                          | 199.5 k $\Omega$ | 200.5 k $\Omega$ |
| 400 k $\Omega$ | 300 k $\Omega$        | OFF                          | 299.3 k $\Omega$ | 300.7 k $\Omega$ |
| 4 M $\Omega$   | 1.2 M $\Omega$        | OFF                          | 1.193 M $\Omega$ | 1.207 M $\Omega$ |
| 4 M $\Omega$   | 3.0 M $\Omega$        | OFF                          | 2.986 M $\Omega$ | 3.014 M $\Omega$ |
| 40 M $\Omega$  | 12 M $\Omega$         | OFF                          | 11.67 M $\Omega$ | 12.33 M $\Omega$ |
| 40 M $\Omega$  | 30 M $\Omega$         | OFF                          | 29.22 M $\Omega$ | 30.78 M $\Omega$ |

DC Millivolts Measurement Test

- 1. Put the calibrator in **Standby** (STBY) mode.
- 2. Put the UUT rotary switch in the **mV** position.
- 3. Connect the calibrator to the **COM** and **mV** terminals on the UUT as shown in Figure 8.
- 4. Apply the values from the calibrator shown in Table 9 and compare the readings on the UUT to the acceptable readings shown.




Figure 8. DC mV Measurement Test Connections


adm005F.EPS

Table 9. DC mV Test

| Range              | Calibrator DC Voltage | Minimum Reading | Maximum Reading |
|--------------------|-----------------------|-----------------|-----------------|
| No Range Switching | 100 mV                | 99.7 mV         | 100.3 mV        |
| No Range Switching | 300 mV                | 299.5 mV        | 300.5 mV        |

**To prevent possible electrical shock, fire, or personal injury:**

- **Some of the calibration verification tests involve the use of high voltages and should be performed by qualified personnel only.**
  - **Always place the calibrator in the Standby (STBY) mode between tests and before handling the test connections or test cables.**
1. Put the calibrator in **Standby** (STBY) mode.
  2. Put the UUT rotary switch in the  $\overline{\overline{V}}$  position; select the autoranging mode.
  3. Connect the calibrator to the **COM** and  $\overline{\Omega}^{\overline{+}}\overline{V}$  terminals on the UUT as shown in Figure 9.
  4. Apply the values from the calibrator shown in Table 10 and compare the readings on the UUT to the acceptable readings shown.



### Figure 9. AC/DC Voltage Measurement Test Connections

adm009F.EPS

Table 10. DC Volts Test

| Range     | Calibrator DC Voltage | Minimum Reading | Maximum Reading |
|-----------|-----------------------|-----------------|-----------------|
| 4 V dc    | 1 V                   | 0.998 V         | 1.002 V         |
| 4 V dc    | 3 V                   | 2.996 V         | 3.004 V         |
| 40 V dc   | 10 V                  | 9.98 V          | 10.02 V         |
| 40 V dc   | 30 V                  | 29.96 V         | 30.04 V         |
| 400 V dc  | 100 V                 | 99.8 V          | 100.2 V         |
| 400 V dc  | 300 V                 | 299.6 V         | 300.4 V         |
| 1000 V dc | 100 V                 | 99              | 101             |
| 1000 V dc | 800 V                 | 798             | 802             |

### AC Volts Measurement Test

#### ⚠⚠ Warning

To prevent possible electrical shock, fire, or personal injury:

- Some of the calibration verification tests involve the use of high voltages and should be performed by qualified personnel only.
  - Always place the calibrator in the Standby (STBY) mode between tests and before handling the test connections or test cables.
1. Put the calibrator in **Standby** (STBY) mode.
  2. Put the UUT rotary switch in the  $\tilde{V}$  position.
  3. Connect the calibrator to the **COM** and  $\Omega V$  terminals on the UUT as shown in Figure 9.
  4. Apply the values from the calibrator shown in Table 11 and compare the readings on the UUT to the acceptable readings shown.

Table 11. AC Volts Test

| Range     | Calibrator Voltage and Frequency | Minimum Acceptable Reading | Maximum Acceptable Reading |
|-----------|----------------------------------|----------------------------|----------------------------|
| 400 mV ac | 100 mV @ 60 Hz                   | 98.9 mV                    | 101.1 mV                   |
| 400 mV ac | 300 mV @ 60 Hz                   | 297.5 mV                   | 302.5 mV                   |
| 4 V ac    | 1 V @ 60 Hz                      | 0.991 V                    | 1.009 V                    |
| 4 V ac    | 2 V @ 60 Hz                      | 1.984 V                    | 2.016 V                    |
| 4 V ac    | 3 V @ 60 Hz                      | 2.977 V                    | 3.023 V                    |
| 40 V ac   | 10 V @ 60 Hz                     | 9.91 V                     | 10.09 V                    |
| 40 V ac   | 30 V @ 60 Hz                     | 29.77 V                    | 30.23 V                    |
| 400 V ac  | 100 V @ 60 Hz                    | 99.1 V                     | 100.9 V                    |
| 400 V ac  | 300 V @ 60 Hz                    | 297.7 V                    | 302.3 V                    |
| 1000 V ac | 100 V @ 60 Hz                    | 97                         | 103                        |
| 1000 V ac | 800 V @ 60 Hz                    | 792                        | 808                        |

## Frequency Measurement Test

1. Put the calibrator in **Standby** (STBY) mode.
2. Put the UUT rotary switch in the  $\tilde{V}$  (ac volts) position.
3. Press Hz to toggle to the frequency measurement function.
4. Connect the calibrator to the **COM** and  $\Omega V$  terminals on the UUT as shown in Figure 10.
5. Apply the values from the calibrator shown in Table 12 and compare the readings on the UUT to the acceptable readings shown. Press RANGE to select the voltage range.

Table 12. Frequency Measurement Test

| UUT        |         | Calibrator Voltage and Frequency | Minimum Acceptable Reading | Maximum Acceptable Reading |
|------------|---------|----------------------------------|----------------------------|----------------------------|
| Range      | Voltage |                                  |                            |                            |
| 199.99 Hz  | 400 mV  | 150 mV @ 100 Hz                  | 99.98 Hz                   | 100.02 Hz                  |
| 1999.9 Hz  | 4 V     | 1 V @ 1000 Hz                    | 999.8 Hz                   | 1000.2 Hz                  |
| 19.999 kHz | 40 V    | 4 V @ 10 kHz                     | 9.998 kHz                  | 10.002 kHz                 |




Figure 10. Frequency Measurement Test Connections

adm010f.EPS

## Calibration Adjustment

The following sections comprise the Calibration Adjustment Procedure. The procedure is meant to bring the UUT back into specification following repair of the UUT or when the UUT fails the Performance Test. The required equipment is listed earlier in Table 2.

Calibrate the ProcessMeter once a year to ensure that it performs according to its specifications.

### Preparation

#### Warning

To prevent possible electric shock, fire, or personal injury:

- Do not use the ProcessMeter if it looks damaged.
- Inspect the ProcessMeter for damage, especially around the input terminals. Inspect the test leads and test connections for damaged insulation or exposed metal.
- Look for cracks, missing plastic or damaged insulation. If damage is detected, do not continue; contact Fluke to have the ProcessMeter serviced.
- Make sure that the battery compartment door on the ProcessMeter is closed and latched before using it.
- Check the test leads for continuity. Replace damaged test leads as necessary.
- Do not use the ProcessMeter if it appears to operate abnormally. Protection designed into the ProcessMeter might be impaired. If in doubt, have the ProcessMeter serviced.
- To avoid electrical shock, always place the calibrator in the Standby (STBY) mode between tests and before handling the test connections or test cables.
- Some of the calibration adjustment procedures involve the use of high voltages and should be performed by qualified personnel only.

**Note**

*The calibration adjustment procedures assume that the person performing them knows how to use the ProcessMeter and the required equipment. Do not attempt to calibrate the ProcessMeter unless you are qualified to do so.*

*Calibration adjustment should be performed in an RF field <1 V/m such as a laboratory environment.*

To prepare for calibration adjustment, do the following:

1. Make sure that you have the required equipment available (see Table 2).
2. Make sure that both fuses in the UUT are intact. See *Check and Replace Fuses* earlier in this manual.
3. Turn on and warm up the calibrator as required by its specifications.
4. Remove all input cables from the front of the UUT.
5. Make sure that the UUT is in an ambient temperature between 18 °C and 28 °C (64.4 °F and 82.4 °F).

**Procedure for Models with Firmware Version <2.0**

**AC Voltage Adjustment**

Connect the ProcessMeter to the volt/ohm output of the 5522A calibrator.

1. Turn the UUT switch to  $\tilde{V}$ .
2. The calibration button is located on the backside of the ProcessMeter, under the Calibration Seal. Use a small probe to break the seal.
3. Press and hold the Calibration Button for approximately 2 seconds. The unit will beep (see Figure 11).

**Note**

*Pressing the Calibration Button puts the ProcessMeter into and out of calibration mode. The ProcessMeter will remain in calibration mode until the unit is turned off or the calibration button is pressed a second time.*


**CAL** appears in the bottom display when the ProcessMeter is in calibration mode.

4. Apply the voltages listed below as prompted by the ProcessMeter.
5. Press  after each sourced value appears. Do not alter the sourced value while the display reads **Busy**.

Applied voltages:

- 4 mV @ 60 Hz
- 40 mV @ 60 Hz
- 400 mV @ 60 Hz
- 4 V @ 60 Hz
- 40 V @ 60 Hz
- 400 V @ 60 Hz
- 1000 V @ 60 Hz

6. When **Store** is displayed, press  to store the calibration value.



**Figure 11. Calibration Button Access**

aau04f.eps

### **Frequency Adjustment**

1. Connect the ProcessMeter to the volt/ohm output of the 5522A calibrator.
2. Turn the UUT's switch to  $\tilde{V}$ .
3. Push .
4. Press and hold the Calibration Button for approximately 2 seconds. The unit will beep (see Figure 11).

#### *Note*

*Press the Calibration Button to put the ProcessMeter into and out of calibration mode. The ProcessMeter remains in calibration mode until the unit is turned off or the calibration button is pressed a second time.*

*CAL appears in the bottom display when the ProcessMeter is in calibration mode.*

5. Apply 4 V @ 5000 Hz.
6. Press  after the sourced value appears. Do not alter the sourced value while the display reads **Busy**.
7. When **Store** displays, press  to store the calibration value.

### DC Voltage Adjustment

1. Connect the ProcessMeter to the volt/ohm output of the 5522A calibrator.
2. Turn the UUT's switch to  $\overline{\text{V}}$ .
3. Press and hold the Calibration Button for approximately 2 seconds. The unit will beep (see Figure 11).

#### Note

*Pressing the Calibration Button puts the ProcessMeter into and out of calibration mode. The ProcessMeter will remain in calibration mode until the unit is turned off or the calibration button is pressed a second time.*

**CAL** appears in the bottom display when the ProcessMeter is in calibration mode.

4. Press  after each sourced value appears. Do not alter the sourced value while the display reads **Busy**.

Applied voltages:

- 0 V
- 4 V
- 40 V
- 400 V
- 1000 V

5. When **Store** is displayed, press  to store the calibration value.

### DC Millivolts Adjustment

1. Connect the ProcessMeter to the volt/ohm output of the 5522A calibrator.
2. Turn the UUT's switch to  $\overline{\text{mV}}$ .
3. Press and hold the Calibration Button for approximately 2 seconds. The unit will beep (see Figure 11).

#### Note

*Pressing the Calibration Button puts the ProcessMeter into and out of calibration mode. The ProcessMeter will remain in calibration mode until the unit is turned off or the calibration button is pressed a second time.*

**CAL** appears in the bottom display when the ProcessMeter is in calibration mode.

4. Apply 0 V. Press  after the sourced value appears. Do not alter the sourced value while the display reads **Busy**.
5. Apply 400 mV. Press  after the sourced value appears. Do not alter the sourced value while the display reads **Busy**.
6. When **Store** is displayed, press  to store the calibration value.

### Ohms Adjustment

1. Connect the ProcessMeter to the volt/ohm output of the 5522A calibrator.
2. Turn the UUT's switch to  $\Omega$ .
3. Press and hold the Calibration Button for approximately 2 seconds. The unit will beep (see Figure 11).

#### Note

*Pressing the Calibration Button puts the ProcessMeter into and out of calibration mode. The ProcessMeter will remain in calibration mode until the unit is turned off or the calibration button is pressed a second time.*

**CAL** appears in the bottom display when the ProcessMeter is in calibration mode.

4. Apply the resistances listed below. Press  after each sourced value appears. Do not alter the sourced value while the display reads **Busy**.

Applied resistances:

- 0  $\Omega$
- 400  $\Omega$
- 4 k $\Omega$
- 40 k $\Omega$
- 400 k $\Omega$
- 4 M $\Omega$
- 40 M $\Omega$

5. When **Store** is displayed, press  to store the calibration value.

### Diode Adjustment

1. Connect the ProcessMeter to the volt/ohm output of the 5522A calibrator.
2. Turn the UUT's switch to  $\Omega$ .
3. Press  $\bigcirc$  (BLUE) to enter the diode function.
4. Press and hold the Calibration Button for approximately 2 seconds. The unit will beep (see Figure 11).

#### Note

*Pressing the Calibration Button puts the ProcessMeter into and out of calibration mode. The ProcessMeter will remain in calibration mode until the unit is turned off or the calibration button is pressed a second time.*

**CAL** appears in the bottom display when the ProcessMeter is in calibration mode.

*Before applying 0 V dc, the 5522A must be range locked in the 3.3 V range. Impedance of 330 mV range changes the 0 V point.*

5. Apply 0 V dc. Press  after the sourced value appears. Do not alter the sourced value while the display reads **Busy**.
6. Apply 1 V dc. Press  after the sourced value appears. Do not alter the sourced value while the display reads **Busy**.
7. When **Store** is displayed, press  to store the calibration value.

### Milliamps DC Adjustment

1. Connect the ProcessMeter to the mA output of the 5522A calibrator.
2. Turn the UUT's switch to  $\tilde{\text{mA}}$ . Make sure the test leads are in the **mA** and **COM** inputs.
3. Press and hold the Calibration Button for approximately 2 seconds. The unit will beep (see Figure 11).

#### Note

*Pressing the Calibration Button puts the ProcessMeter into and out of calibration mode. The ProcessMeter will remain in calibration mode until the unit is turned off or the calibration button is pressed a second time.*

**CAL** appears in the bottom display when the ProcessMeter is in calibration mode.

4. Apply 0 mA dc. Press  after the sourced value appears. Do not alter the sourced value while the display reads **Busy**.
5. Apply 30 mA dc. Press  after the sourced value appears. Do not alter the sourced value while the display reads **Busy**.
6. When **Store** is displayed, press  to store the calibration value.

### Amps DC Adjustment

1. Connect the ProcessMeter to the A output of the 5522A calibrator.
2. Turn the UUT's switch to  $\tilde{\text{A}}$ . Make sure the test leads are in the **A** and **COM** jacks.
3. Press and hold the Calibration Button for 2 seconds (see Figure 11). The unit will beep.
4. Apply 0 A dc. Press  after the reading stabilizes.
5. Apply 1 A dc. Press  after the reading stabilizes.

#### Caution

**Remove 1 A from UUT promptly after storing calibration constant.  
Fuse will blow after 30 seconds.**

6. Press  to store calibration constants.

### *Amps AC Adjustment*

1. Connect the ProcessMeter to the A output of the 5522A calibrator.
2. Turn the UUT's switch to  $\tilde{\text{mA}}$ .
3. Press  (BLUE) to enter the A ac function.
4. Press and hold the Calibration Button for 2 seconds (see Figure 11). The unit will beep.
5. Apply 0.05 A ac @ 60 Hz. Press  after the reading stabilizes.
6. Apply 1 A ac. Press  after the reading stabilizes.
7. Press  to store calibration constants.

### **Caution**

**Remove 1 A from UUT promptly after storing calibration constant.  
Fuse will blow after 30 seconds.**

### *Milliamps Output Adjustment*

1. Connect the ProcessMeter A output to the Digital Multimeter input.
2. UUT will output approximately 4 mA. Use the fine and coarse adjustments on the UUT to get a 4.000 mA reading on the Digital Multimeter.
3. Press  after 4.000 mA reading is reached on the Digital Multimeter.
4. UUT will output approximately 20 mA. Use the fine and coarse adjustments on the UUT to get a 20.000 on the Digital Multimeter.
5. Press  after 20.000 mA reading is reached on the Digital Multimeter.
6. Press  to store calibration constants.

## Procedure for Models with Firmware Version ≥2.0

### Calibration Adjustment Counter

The Meter contains a calibration adjustment counter. The counter is incremented each time a Calibration Adjustment Procedure is completed. The value in the counter can be recorded and used to show that no adjustments have been made during a calibration cycle.

Use the following steps to view the calibration counter on the UUT.

1. While holding down **[HOLD]** on the UUT, turn the rotary switch from **OFF** to  $\Omega \rightarrow +$ . The UUT should display **[RL]**. Release **[HOLD]**.
2. Press **[HOLD]** once to see the calibration counter. For example, **n00 l**.
3. Turn the rotary switch to **OFF**.

### Calibration Adjustment Password

To start the Calibration Adjustment Procedure, the correct four-digit password must be entered. The password can be changed or reset to the default as described in following paragraphs. The default password is **1234**.

### How to Change the Password

1. While holding down **[HOLD]** on the UUT, turn the rotary switch from **OFF** to  $\Omega \rightarrow +$ . The UUT displays **[RL]**. Release **[HOLD]**.
2. Press **[HOLD]** once to see the calibration counter.
3. Press **[HOLD]** again to start the password entry. The UUT displays **????**.

The following keys represent the digit indicated below when entering or changing the password:

|                 |                    |                  |                 |
|-----------------|--------------------|------------------|-----------------|
| <b>100%</b> = 1 | <b>MIN MAX</b> = 2 | <b>RANGE</b> = 3 | <b>HOLD</b> = 4 |
| <b>0%</b> = 5   | <b>    </b> = 6    | <b>REL Δ</b> = 7 | <b>Hz</b> = 8   |
| <b>⚙</b> = 9    |                    | <b>○</b> = 0     |                 |

4. Press the four keys to enter the old password. If changing the password for the first time, enter **100%** (1), **MIN MAX** (2), **RANGE** (3), and **HOLD** (4).
5. Press **[RANGE]** to change the password:
  - The UUT displays **----** if the old password is correct.
  - If the password is not correct, the UUT emits a double beep, displays **????** and the password must be entered again. Repeat step 4.
6. Press the four keys representing the new password.
7. Press **[HOLD]** to store the new password.



# Static Awareness




Semiconductors and integrated circuits can be damaged by electrostatic discharge during handling. This notice explains how to minimize damage to these components.

1. Understand the problem.
2. Learn the guidelines for proper handling.
3. Use the proper procedures, packaging, and bench techniques.


Follow these practices to minimize damage to static sensitive parts.

## Warning

**To prevent electric shock or personal injury. De-energize the product and all active circuits before opening a product enclosure, touching or handling any PCBs or components.**



- Minimize handling.
- Handle static-sensitive parts by non-conductive edges.
- Do not slide static-sensitive components over any surface.
- When removing plug-in assemblies, handle only by non-conductive edges.
- Never touch open-edge connectors except at a static-free work station.



- Keep parts in the original containers until ready for use.
- Use static shielding containers for handling and transport.
- Avoid plastic, vinyl, and Styrofoam® in the work area.



- Handle static-sensitive parts only at a static-free work station.
- Put shorting strips on the edge of the connector to help protect installed static-sensitive parts.
- Use anti-static type solder extraction tools only.
- Use grounded-tip soldering irons only.

## How to Restore the Default Password

### ⚠⚠ Warning

To avoid electrical shock or personal injury, remove the test leads and any input signal before removing the back case from the UUT.

If the calibration password is forgotten, the default password (1234) can be restored with these steps:

1. Turn the rotary switch from **OFF** to **✓**.
2. Remove the back case from the UUT.
3. Remove the shield and leave the PCA in the top case.
4. Apply 6.0 V across the battery pads (XBT1) + and – on the back of the PCA. See Figure 10.
4. Short across the **Cal** keypad on the back of the PCA. See Figure 10. The UUT should beep (if the beeper is enabled). The default password is now restored.
5. Remove the 6.0 V supply and install the shield and back case on the UUT.




Figure 12. Restoring the Default Password


### Meter Keys Used in the Calibration Steps

The Meter keys behave as follows when performing the Calibration Adjustment Procedure. This may be of help determining why a calibration step is not accepted and for determining the input value without referring to Table 6.

-  Press and hold to show the measured value. The measurement value is not calibrated so it may not match the input value. This is normal.
-  Press and hold to display the required input amplitude.
-  Press and hold to display the frequency of the required input.
-  Store the calibration value and advance to the next step. This key is also used to exit the calibration mode after the calibration-adjustment sequence is complete.
-  Press to adjust the Source mA to the target.

### Calibration Adjustment

Use the following steps to make calibration adjustments to the UUT. Complete the adjustment procedure before turning the UUT off; otherwise, the new calibration constants will not be saved.

- While holding down , turn the rotary switch from **OFF** to . The UUT displays . Release .
- Press  once to see the calibration counter, for example, .
- Press  again to start the password entry. The UUT displays .
- Press four keys to enter the password.
- Press  to go to the first calibration step. The UUT displays  if the password is correct. If the password is not correct, the UUT emits a double beep, displays  and the password must be entered again. Repeat step 4.
- Apply the input value listed for each calibration adjustment step in Table 13. For each step, position the rotary switch and apply the input to the terminals as indicated in the table.
- After each input value is applied, press  to accept the value and proceed to the next step ( and so forth).

#### Note

Press  and wait until the step number advances before changing the calibrator source or turning the rotary switch. If the rotary switch is not in the correct position, or if the measured value is not within the anticipated range of the input value, the UUT emits a double beep and will not continue to the next step. Some adjustment steps take longer to execute than others (10 to 15 seconds). For these steps, the UUT will beep when the step is complete. Not all steps have this feature.

- After the final step, the display shows  to indicate that the calibration adjustment is complete. Press  to go to meter mode.

**Note**

*Set the calibrator to Standby prior to changing the function switch position and/or after completing adjustment of each function. If the calibration adjustment procedure is not completed correctly, the UUT will not operate correctly.*

**⚠ Caution**

**Remove 1 A from UUT promptly after storing calibration constant.  
Fuse will blow after 30 seconds.**

**Table 13. Calibration Adjustment Steps for Models with Firmware Version >2.0**

| Input Terminal | Step | Input Value                                                        | Function  |
|----------------|------|--------------------------------------------------------------------|-----------|
| V/COM          | 1    | 400 mV ac, 60 Hz                                                   | V ac      |
|                | 2    | 4 V ac, 60 Hz                                                      | V ac      |
|                | 3    | 40 V ac, 60 Hz                                                     | V ac      |
|                | 4    | 400 V ac, 60 Hz                                                    | V ac      |
|                | 5    | 4 V dc                                                             | V dc      |
|                | 6    | 40 V dc                                                            | V dc      |
|                | 7    | 400 V dc                                                           | V dc      |
|                | 8    | 400 mV dc                                                          | mV dc     |
|                | 9    | 40 mV dc                                                           | mV dc     |
|                | 10   | 400 Ω                                                              | Ω         |
|                | 11   | 4 kΩ                                                               | Ω         |
|                | 12   | 40 kΩ                                                              | Ω         |
|                | 13   | 400 kΩ                                                             | Ω         |
|                | 14   | 4 MΩ                                                               | Ω         |
|                | 15   | 0 MΩ                                                               | Ω         |
|                | 16   | 40 MΩ                                                              | Ω         |
|                | 17   | 4 V dc                                                             | Diode     |
| mA/COM         | 18   | 0 mA dc                                                            | mA        |
|                | 19   | 30 mA dc                                                           | mA        |
| A/COM          | 20   | 1 A dc                                                             | A         |
|                | 21   | 1 A ac, 60 Hz                                                      | A         |
|                | 22   | 1 A ac, 2 kHz                                                      | A         |
| A/mA           | 23   | No input, 0 % (4 mA) output, measure output current with HP3458    | mA source |
|                | 24   | No input, 100 % (20 mA) output, measure output current with HP3458 | mA source |

## Replacement Parts and Accessories


### ⚠⚠ Warning

To prevent possible electrical shock, fire, or personal injury use only:

- Use only specified replacement fuses.
- Use only specified replacement parts.

Replacement parts and some accessories are shown in Figure 13 and listed in Table 14. Many more DMM accessories are available from Fluke. For a catalog, contact the nearest Fluke distributor.

To find out how to order parts or accessories use the telephone numbers or addresses shown in "Contacting Fluke."



**Table 14. Replacement Parts**

| Item Number | Description                                                                                                      | Fluke PN for 789 <V2    | Fluke PN for 789 ≥V2 | Fluke PN for 787B | Quantity     |
|-------------|------------------------------------------------------------------------------------------------------------------|-------------------------|----------------------|-------------------|--------------|
| 1           | Knob Assembly with o-ring                                                                                        | 658440                  |                      | 4772670           | 1            |
| 2           | Decal, Top Case                                                                                                  | 1623923                 |                      | 4772201           | 1            |
| 3           | Keypad                                                                                                           | 1622951                 |                      |                   | 1            |
| 4           | Top Shield                                                                                                       | 1622924                 | 4772681              |                   | 1            |
| 5           | Top Shield Contact                                                                                               | 674853                  |                      |                   | 1            |
| 6           | LCD Display                                                                                                      | 1883431                 |                      |                   | 1            |
| 7           | LCD Connectors, Elastomeric                                                                                      | 1641965                 |                      |                   | 2            |
| 8           | Backlight/Bracket                                                                                                | 1622960                 | 4756199              |                   | 1            |
| 9           | Top Case with Lens Protector                                                                                     | 1622855                 |                      | 4772197           | 2            |
| 10          | Contact Housing                                                                                                  | 1622913                 |                      |                   | 1            |
| 11          | RSOB Contact                                                                                                     | 1567683                 |                      |                   | 4            |
| 12          | Mask                                                                                                             | 1622881                 |                      | 4772655           | 1            |
| 13          |  Fuse, 440 mA, 1000 V fast-blow | 943121                  |                      |                   | 2            |
| 14          | PCB Screw                                                                                                        | 832220                  |                      |                   | 2            |
| 15          | Battery Contact, Negative                                                                                        | 658382                  |                      |                   | 1            |
| 16          | Battery Contact, Positive                                                                                        | 666438                  |                      |                   | 1            |
| 17          | Battery Contacts Dual                                                                                            | 666435                  |                      |                   | 3            |
| 18          | Bottom Insulator                                                                                                 | NA                      | 4811256              |                   | 1            |
| 19          | Bottom Shield                                                                                                    | 1675171                 | 4811263              |                   | 1            |
| 20          | Shock Absorber                                                                                                   | 878983                  |                      |                   | 1            |
| 21          | IR Lens                                                                                                          | 658697                  |                      |                   | 1            |
| 22          | Bottom Case                                                                                                      | 659042                  | 4772662              |                   | 1            |
| 23          | Case Screws                                                                                                      | 1558745                 |                      |                   | 4            |
| 24          | Battery, 1.5 V, 0-15 mA, AA Alkaline                                                                             | 376756                  |                      |                   | 4            |
| 25          | Accessory Mount with Probe Holders                                                                               | 658424                  |                      |                   | 1            |
| 26          | Shock Absorber                                                                                                   | 674850                  |                      |                   | 1            |
| 27          | Access Door, Battery/Fuse                                                                                        | 1622870                 |                      |                   | 1            |
| 28          | Fasteners, Battery/Fuse Access Door                                                                              | 948609                  |                      |                   | 2            |
| 29          | Tilt-Stand                                                                                                       | 659026                  |                      |                   | 1            |
| -           | Test Leads                                                                                                       | variable <sup>[1]</sup> |                      |                   | 1 (set of 2) |
| -           | Alligator Clips                                                                                                  | variable <sup>[1]</sup> |                      |                   | 1 (set of 2) |
| [1] _____   |                                                                                                                  |                         |                      |                   |              |